



RECOMMENDED SAMPLING INTERVALS

V3	V7	V10	VT	R1, R3
----	----	-----	----	--------

* Samples prior to V3 can be of the whole plant or single leaf sets.

Corn Leaf Sampling Instructions

1. Collect **NEW** leaves and **OLD** leaves **SEPARATELY** in individually labeled bags:
 - New = newest recently-mature growth from the top of the plant.
 - Old = oldest still-viable growth from the base of the plant.
2. Collect a **representative field sample** including one new leaf and one old leaf from 10-15 plants of the same cultivar and growing conditions. Each sample (new and old) should fill a **1qt plastic bag**.
 - For larger leaves (e.g. after V6/V7) stack and roll leaves to fit in a 1gal bag.
3. **Remove petioles** and all other non-leaf plant material from sample leaves.
4. Complete a Leaf [Sampling Label](#) (linked) with your contact info, crop, cultivar, field/block info, new/old leaf, and desired agronomy services. Affix labels to the **outside** of each sealed plastic sample bag.
(Do not use paper bags or include paper in bags)
5. **Keep samples viable** by minimizing shipping time and using cold-packs and/or insulated packaging when shipping leaves in warm conditions. Wrap frozen cold-packs in paper to insulate them from direct contact with samples.
6. Mail samples (*including payment if paying with check or money order*) to:

Apical Crop Science LLC
1382 SE 3rd Ave, Suite 4
Canby, OR 97013

DO NOT SEND ANY INTERNATIONAL LEAF, SOIL, OR WATER SAMPLES WITHOUT PRIOR WRITTEN APPROVAL FROM APICAL.

TIPS FOR BEST RESULTS:

- [Request Apical's Agronomy Services](#) for nutrient *Target Range Charts* and *Detailed Recommendations*.
- [Include notes](#) about growth stage, health, pests/disease, and other points that will help us serve you.
- [Be proactive](#) by conducting 5-7 Leaf Extract Analyses throughout the growing (recommended sampling intervals listed in the table above).
- [Solve stress, pests, or toxicities](#) by testing and treating weekly until optimal health is achieved.
- [Collect leaves at a consistent time](#) of day, preferably prior to 10 a.m. to ensure minimal transpiration - about two hours after sunrise is optimal. For indoor, sample within one hour of light cycle start.
- [Ensure leaves are clean](#) of dew, dirt, and fertilizers - wash with clean, cold, non-chlorinated water if needed.
- [Ensure leaves are surface-dry](#) (not dried out) before bagging - use a paper towel or air-dry if needed.

*Please do NOT leave paper towels (or anything that will dry out leaves) in bags with samples.