



EARLY LEAF

SHOOT EXTENSION

FLOWERING

EMBRYO

KERNEL

DORMANT

HAZELNUT: RECOMMENDED SAMPLING INTERVALS

When available, collect samples from canes that will bear fruit in current season.

Submission Instructions

1. **Collect** NEW leaves and OLD leaves SEPARATELY in individually labeled bags:
 - New = newest recently-mature growth from the top of the plant
 - Old = oldest still-viable growth from the bottom of the plant
2. **Gather** a representative field sample by pulling multiple new leaves and multiple old leaves from 15+ plants of the same cultivar, block/field. Collect enough leaves so that each sample (new and old) will fill a 1 quart Ziploc bag or Apical submission bag.
 - a. For larger leaves (e.g. after V6/V7) stack and roll leaves to fit in a 1gal bag.
3. **Remove** petioles and all other non-leaf plant material from sample leaves.
4. **Fill** out Leaf Extract Analysis report order form online at www.apical-ag.com/grower/order.
5. **Print** out submission forms and attach necessary forms to each submission bag.
6. **Ensure** samples remain viable by minimizing shipping time and using cold packs and/or insulated packaging when shipping in warm conditions. Wrap frozen cold packs in paper to insulate them from direct contact with sample bags.
7. **Mail** samples (including check/money order or paid submission form) to:

Apical Crop Science LLC
1382 SE 3rd Ave, Suite 4
Canby, OR 97013

DO NOT SEND ANY INTERNATIONAL LEAF, SOIL, WATER, OR CNA SAMPLES WITHOUT PRIOR WRITTEN APPROVAL FROM APICAL. SUBMISSIONS THAT DO NOT COMPLY WITH THE ESTABLISHED SAMPLING PROTOCOL WILL BE DEEMED INVALID.

TIPS FOR BEST RESULTS:

1. Achieve optimal plant health by conducting the above LEA sampling process and applying Apical's tailored recommendations consistently throughout the growing season.
2. Always sample at a consistent time of day, preferably prior to 10am to ensure minimal transpiration — about two hours after sunrise is optimal. For indoor plants, sample within one hour of light cycle start.
3. Ensure samples are as clean as possible — dew, dirt, dust, and fertilizers can affect test accuracy.
 - If samples are not clean, wash leaves with clean, non-chlorinated cold water.
4. Ensure samples are surface-dry (not dried out) before bagging — dew, rain, and condensation affect accuracy.
 - If samples are not dry, please dry with paper towel or air dry to ensure leaves are not wet in sample bags.
 - Please do NOT leave any paper (labels, paper towels, etc.) in bags with samples.